


SIEMENS

F
RM
SB
DM1
DM2
L1
L2

P1
P2
P3
P4
P5
P6
P7
P8

SCALANCE XC208G



SELECT/
SET



CONSOLE



FAULT

F1
F2
L1+
M1
M2
L2+



P1 TO P8 FOR LAN ONLY
208-UGA00-2AC2

