

Instrucciones de montaje
Installation Instructions
Notice d'installation
Istruzioni per il montaggio
Montageanweisung
Montagehandleiding

Montagevejledning
Οδηγίες εγκατάστασης
Instruções de montagem
Monteringsanvisning
Asennusohje
Návod k montáži

Paigaldusjuhend
Szerelési utasítás
Montázs instrukcija
Montavimo instrukcija
Instrukcja montażu
Navodila za montažo

Návod na montáž
Монтажни инструкции
Instrucțiuni de montaj
Инструкция по монтажу
安装说明

IEC/EN 62208



$A_c \leq 1000V$ $I_n < 125A$

$D_c \leq 1500V$ $F_r < 100Hz$


IEC/EN 60674-24

$A_c \leq 400V$ $I_n < 125A$




$D_c \leq 400V$ $F_r < 100Hz$








94273 - M25




94274 - M40







/



+



94273 - M25

+

